



SPEC 30 Universal Packing Kit Installation Instructions

Thank you for choosing Bristol Core's Spec 30 Packing Kit for your repack job. These instructions will simplify your repack and ensure the best performance possible.

Step 1 – Disassemble your muffler. Remove the front end-cap fasteners. Separate the muffler from the end-cap.

Tip - If there is a silicone seal present, carefully cut through the seal with a knife.



Step 2 - Remove any old packing that remains. Clean the core with a wire brush and inspect it for cracks, especially near welds.

Step 3 – Take a measurement for trimming the Spec 30 Pillow. If the end caps of the muffler are packable, the pillow will need to be trimmed so that it covers the rest of the exposed core. Lay the core on the pillow and mark it. Cut through the pillow with a pair of sturdy scissors. Take small bites as you cut.



Step 4 – Stuff the end-caps. Using the cap stuffing pillows, stuff any end-caps that will accept packing. Normally, these do not need to be trimmed and the entire pillow should get used.



Step 5 – Position and roll the pillow. Remove the backing paper from the pillow. Position the pillow on a work surface so that the end cap that is attached to the core (if one is welded to it) can hang off the end edge of the work surface. Doing so will allow you to roll the pillow to a smaller diameter than the muffler's shell which is what you want to do.



Step 6 – Reassemble the muffler.